



# ScanCast™ Action Barcodes:


Omnicell - Omnicell CPM - SCRXCOPM – Large (3x3)




Reset



Quantity



Enable <sup>[1]</sup>




Disable

[1] On power-on the module will be enabled. [2] This setting is non-volatile and will be retained over power-cycles. [3] Factory Setting: Output On [4] Factory Setting: Output Off




# ScanCast™ Action Barcodes:

Omnicell - Omnicell CPM - SCRXCOPM - Large (3x3)



Toggle Group Separator <sup>[2,4]</sup>



Toggle Line Ending <sup>[2,3]</sup>

[1] On power-on the module will be enabled. [2] This setting is non-volatile and will be retained over power-cycles. [3] Factory Setting: Output On [4] Factory Setting: Output Off