



# ScanCast™ Action Barcodes:


SwissLog - Receiver for SwissLog Receiving - SCRXLRX  
Large (3x3)




Reset



Accept



Confirm



Enable <sup>[1]</sup>

[1] Default setting after a power cycle


[2] Factory default setting

[3] Setting is stored in non-volatile memory and will be retained over power-cycles.




# ScanCast™ Action Barcodes:


SwissLog - Receiver for SwissLog Receiving - SCRXSLRX  
Large (3x3)




Disable



Enable Lot <sup>[3]</sup>



Disable Lot <sup>[2][3]</sup>



Single Scan Mode Enabled <sup>[3]</sup>

[1] Default setting after a power cycle


[2] Factory default setting

[3] Setting is stored in non-volatile memory and will be retained over power-cycles.



# ScanCast™ Action Barcodes:

SwissLog - Receiver for SwissLog Receiving - SCRXSLRX  
Large (3x3)



Single Scan Mode Disabled <sup>[2]</sup><sup>[3]</sup>

[1] Default setting after a power cycle

[2] Factory default setting

[3] Setting is stored in non-volatile memory and will be retained over power-cycles.