

# ScanCast™ Action Barcodes:

Configure RI110081 Output Format



Raw Output



NDC



UPC



GTIN <sup>[1]</sup>



GS1  
(Honeywell)

[1] Default setting

## Additional Notes

ScanCast will attempt to output the format requested, however, it will not fabricate data to create output. This means if the ScanCast is set to output a GTIN, but a UPC is scanned, a UPC will be output. The order of data from most information to least is: GS1 > GTIN > UPC > NDC.

All these configuration barcodes change settings stored in non-volatile memory in the ScanCast™ and will be retained across power cycles.