


ScanCast™ Action Barcodes:

For Model # [R1110081] Large (3x3)




Reset



Quantity



Enable ^[1]



Disable

[1] On power-on the module will be enabled. [2] This setting is non-volatile and will be retained across power-cycles. [3] Factory Setting: Output On [4] Factory Setting: Output Off

ScanCast™ Action Barcodes:

For Model # [RI110081] Large (3x3)



Intentionally left blank.

ScanCast™ Action Barcodes:


For Model # [R1110081] Large (3x3)




Toggle Group Separator^[2,4]



Toggle Line Ending^[2,3]



Quantity By Default
(Automatic)



Quantity By Request
(Manual)

[1] On power-on the module will be enabled. [2] This setting is non-volatile and will be retained across power-cycles. [3] Factory Setting: Output On [4] Factory Setting: Output Off

ScanCast™ Action Barcodes:

For Model # [RI110081] Large (3x3)



Intentionally left blank.