



ScanCast™ Action Barcodes:


RI060091 - Medium (1.75x1.75)




Reset




Continue




Free Scan Mode



Add Zero



Up ^[1]




Down ^[1]


[1] This action is available from any state. [2] Default Setting on Power-up. [3] This setting is stored in Non-volatile memory and will be retained over power-cycles. [4] This is the factory default setting.

ScanCast™ Action Barcodes:


RI060091 - Medium (1.75x1.75)




Yes ^[1]




No ^[1]




Enter ^[1]



F2 ^[1]



Enable ^[2]




Disable


[1] This action is available from any state. [2] Default Setting on Power-up. [3] This setting is stored in Non-volatile memory and will be retained over power-cycles. [4] This is the factory default setting.

ScanCast™ Action Barcodes:

RI060091 - Medium (1.75x1.75)



Workflow A ^[3,4]



Workflow B ^[3]

[1] This action is available from any state. [2] Default Setting on Power-up. [3] This setting is stored in Non-volatile memory and will be retained over power-cycles. [4] This is the factory default setting.