



ScanCast™ Action Barcodes:


RR020084 - Large (3x3)




Quantity



Confirm



Send to Queue




Reset

[1] Default setting after power-on.


[2] This setting is non-volatile and will be retained over power-cycles.

ScanCast™ Action Barcodes:


RR020084 - Large (3x3)




Enable ^[1]



Disable



Line Ending Carriage Return ^[2]




Line Ending Line Feed ^[2]

[1] Default setting after power-on.

[2] This setting is non-volatile and will be retained over power-cycles.

ScanCast™ Action Barcodes:

RR020084 - Large (3x3)



Line Ending Carriage Return/
Line Feed^[1,2]

[1] Default setting after power-on.

[2] This setting is non-volatile and will be retained over power-cycles.