



ScanCast™ Action Barcodes:


For Model Number [RI120074] Large (3x3)




Reset



Enable^[1]



Disable



Lot

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Large (3x3)




Intentionally left blank.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Large (3x3)




Expiration



Expiration Date Disabled^[2]



Expiration Date
Enabled^[2]



Expiration Date
Enabled (add **) ^[2]

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Large (3x3)




Intentionally left blank.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Large (3x3)




Quantity



Quantity Disabled^[2]



Quantity Enabled^[2]



Quantity Enabled (add *)^[2]

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Large (3x3)




Intentionally left blank.

ScanCast™ Action Barcodes:

For Model Number [RI120074] Large (3x3)



Output Mode:
Keyboard ^[2]



Output Mode:
USB Serial ^[2]

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:

For Model Number [RI120074] Large (3x3)



Intentionally left blank.