



ScanCast™ Action Barcodes:


For Model Number [RI120074] Medium (1.75x1.75)




Reset




Enable^[1]




Disable



Lot



Output Mode:
Keyboard^[2]



Output Mode:
USB Serial^[2]

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Medium (1.75x1.75)




Intentionally left blank.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Medium (1.75x1.75)




Expiration




Quantity




Expiration Date Enabled ^[2]



Quantity Enabled ^[2]



Expiration Date Enabled (add **) ^[2]



Quantity Enabled (add *) ^[2]

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:


For Model Number [RI120074] Medium (1.75x1.75)




Intentionally left blank.

ScanCast™ Action Barcodes:

For Model Number [RI120074] Medium (1.75x1.75)



Expiration Date Disabled ^[2]



Quantity Disabled ^[2]

[1] Default setting at power on.

[2] Setting is maintained across power cycles.

ScanCast™ Action Barcodes:

For Model Number [RI120074] Medium (1.75x1.75)



Intentionally left blank.