

ScanCast™ Action Barcodes:

For Model# [RR020084] Small (0.64x0.64)



Quantity



Confirm



Send to Queue



Reset



Enable^[1]



Disable



Line Ending Carriage
Return^[2]



Line Ending Line Feed^[2]



Line Ending Carriage
Return/Line Feed^[2]

[1] Default setting after power-on.

[2] This setting is non-volatile and will be retained over power-cycles.

ScanCast™ Action Barcodes:

For Model# [RR020084] Small (0.64x0.64)



Intentionally left blank.